

阅读申明


- 1.本站收集的数据手册和产品资料都来自互联网，版权归原作者所有。如读者和版权方有任何异议请及时告之，我们将妥善解决。
- 2.本站提供的中文数据手册是英文数据手册的中文翻译，其目的是协助用户阅读，该译文无法自动跟随原稿更新，同时也可能存在翻译上的不当。建议读者以英文原稿为参考以便获得更精准的信息。
- 3.本站提供的产品资料，来自厂商的技术支持或者使用者的心得体会等，其内容可能存在描述上的差异，建议读者做出适当判断。
- 4.如需与我们联系，请发邮件到marketing@iczoom.com，主题请标有“数据手册”字样。

Read Statement

1. The datasheets and other product information on the site are all from network reference or other public materials, and the copyright belongs to the original author and original published source. If readers and copyright owners have any objections, please contact us and we will deal with it in a timely manner.
2. The Chinese datasheets provided on the website is a Chinese translation of the English datasheets. Its purpose is for reader's learning exchange only and do not involve commercial purposes. The translation cannot be automatically updated with the original manuscript, and there may also be improper translations. Readers are advised to use the English manuscript as a reference for more accurate information.
3. All product information provided on the website refer to solutions from manufacturers' technical support or users the contents may have differences in description, and readers are advised to take the original article as the standard.
4. If you have any questions, please contact us at marketing@iczoom.com and mark the subject with "Datasheets" .

April Development Board

April is a very simple board with the minimum required components for a working impee.



Project Files

[Schematics](#)

[Gerber Files](#)

[Bill of Materials](#)

[Altium Source Files](#)

Power

Power can be supplied using a USB-Mini-B cable from a USB Charger or standard USB Port, though the data lines are not connected to anything. Optionally, a battery connector can be soldered to the battery pads, P+, P-. April can operate from any DC voltage from 3.3 to 17 Volts, and tolerates voltages down to -12 Volts. This is helpful for any application with removable batteries where they may be inserted backwards by the user. You may select between USB power and battery power by placing a shunt on the power select header. Please note that April does not have any circuitry for charging a battery and you should never short USB power to the battery pack.

April uses the TI TPS62172 DC/DC Buck Power supply for 3.3V. It can provide an additional 100mA@3V3 to any boards connected to April, however if your application requires more than 100mA@3V3, it must have it's own supply.

The 3 pin jumper allows selection of the DC input source; jumper between the middle pin and the side labeled USB for USB power, and the other way for battery pack power (soldering the input leads onto the P+ and P- pads).

Signals

All of the signals from the imp come out to a header. For descriptions of pin of function see the [Imp Pin Mux](#).

Card Detect

If your application requires the card detect signal, it must be pulled up by soldering an 0402 resistor R3 or on an external board.. The signal is connected to GND whenever a card is present in the slot, so we recommend using a 100kΩ or higher resistor to save power.

VIN

This pad is connected to the input voltage being fed to the board - either the USB 5v supply or the reverse-voltage protected battery pads.

april.txt · Last modified: 2012/10/03 00:53 by hugo

Except where otherwise noted, content on this wiki is licensed under the following license: CC Attribution-Share Alike 3.0 Unported [<http://creativecommons.org/licenses/by-sa/3.0/>]